

GATEKEEPER OFF-ROAD

Knuckle Pod Mounts Installation Instructions

Dana 30/44 Mounts (TJ and JK Installation Similar)

Tools Needed:

- Standard socket Set
- 13mm 12 point Socket or Wrench
- Torque Wrench
- 3/32 Rivet Tool

Parts Included:

- (2) Steel Knuckle Pod Mounting Brackets
- (2) Logo plates
- (4) 3/32 rivets

Installation:

1. After painting the logo and bracket to desired color, rivet the logo plate to the mounting bracket in the correct orientation as shown in the picture (Blue)
2. On a level surface, safely place the front axle on jack stands so that the weight is off the tires.
3. Remove wheels from the front axle to gain more room for installation.
4. Using a 13mm 12 point socket or wrench, remove the front and upper hub bolts only (Green).
5. Place the mounting bracket on the hub as shown in the picture above (Green).
6. Reinstall the factory bolts and TORQUE to manufacturer specifications.
7. Install lights and check clearances when steering side to side.

