

INSTALL INSTRUCTIONS:

- 1- Turn the wheel to allow easy access. (For front install)**
- 2- Remove the bottom shock mounting nut and or bolt.**
- 3- Anchor can be mounted with the bolt installed from either direction (finger tighten bolt).**
- 4- Determine and adjust bracket length by selecting the appropriate mounting hole. Bend if necessary and trim excess bracket as required.**
- 5- Final install to prevent any line interference or excessive stretching at full droop, turn and compression.**
- 6- Install 3 zip ties at the anchor and as necessary on the lines. Torque shock mount bolt. (40 ft.lbs)**